



**Lift
Assembly**



Remove and Install Head Assembly



Remove and Install Adapter Bracket

**Auger / Housing Lift
Assembly for Beehive
Separator Units**



Remove and Install Feed Screws

Advantages:

- **Available for most Beehive Separator Units.**
- **Easily Removes Head Housing Assembly and Adapter Bracket.**
- **Easily Remove Both Feed Screws At Once.**
- **Allows easy removal of augers and housings without risk of dropping.**
- **Saves wear and tear on parts.**
- **Provides Safe Work Environment.**
- * **For additional information and firm prices, please contact Beehive, Inc. (A Weiler Company)**

Weiler® and Company, Inc., 1116 East Main Street, Whitewater, Wisconsin, 53190, USA PHONE: (262) 473-5254 (800) 558-9507 FAX: (262) 473-5867
 Weiler® Food Processing Equipment Canada Ltd., 485 James Street South, St. Marys, Ontario, N4X 1B7, CANADA PHONE: (519) 349-2620 FAX: (519) 349-2631
 Beehive, Inc. 9100 South 500 West Sandy, Utah, USA PHONE: (801) 561-4211 (800) 621-8438 FAX: 801-562-5857
 Weiler® Food Processing Equipment (Europe) Ltd., Unit 60, Waverley Road, The Beeches Industrial Estate, Yate, Bristol, BS37 5QR, ENGLAND
 PHONE: +44 (0) 1454 320900 FAX: +44 (0) 1454 326262